


## Documentatie tehnica motor ruris 5500rs/5500r/LP-PT-02



| Nr.crt | Denumire produs        | Product name                      | Cod comanda   |
|--------|------------------------|-----------------------------------|---------------|
| 1      | demaror                | Start Assy                        | ps5500rs-1-1  |
| 2      | carcasa ventilator     | Wind scooper                      | ps5500rs-1-2  |
| 3      | piulita                | Nut                               | ps5500rs-1-3  |
| 4      | carcasa toba esapament | Muffler cover                     | ps5500rs-1-4  |
| 5      | toba esapament         | Muffler Assy.                     | ps5500rs-1-5  |
| 6      | garnitura evacuare     | Heat Insulation Gasket of Muffler | ps5500rs-1-6  |
| 7      | prezon                 | Double head bolt                  | ps5500rs-1-7  |
| 8      | garnitura              | Gasket of Respirator              | ps5500rs-1-8  |
| 9      | placa                  | Respirator Cover Plate            | ps5500rs-1-9  |
| 10     | surub                  | Hexagon flange bolts              | ps5500rs-1-10 |
| 11     | piulita                | Nut                               | ps5500rs-1-11 |
| 12     | cuplaj                 | Drived disk                       | ps5500rs-1-12 |
| 13     | ventilator             | Fan                               | ps5500rs-1-13 |
| 14     | volanta                | Flywheel                          | ps5500rs-1-14 |
| 15     | simering               | Oil seal                          | ps5500rs-1-15 |
| 16     | piulita                | Nut                               | ps5500rs-1-16 |

## Producător motoutilaje

## Documentatie tehnică

|    |                           |                            |               |
|----|---------------------------|----------------------------|---------------|
| 17 | prezon                    | Double head bolt           | ps5500rs-1-17 |
| 18 | prezon                    | Double head bolt           | ps5500rs-1-18 |
| 19 | surub                     | Hexagon flange bolts       | ps5500rs-1-19 |
| 20 | supapa                    | Valve Element              | ps5500rs-1-20 |
| 21 | surub                     | Cross head screw           | ps5500rs-1-21 |
| 22 | placuta de ghidare        | Push rod assy.             | ps5500rs-1-22 |
| 23 | simering                  | Oil seal                   | ps5500rs-1-23 |
| 24 | tacheti                   | Tappets                    | ps5500rs-1-24 |
| 25 | tija                      | Push rod assy.             | ps5500rs-1-25 |
| 26 | prezon                    | Adjustment bolt            | ps5500rs-1-26 |
| 27 | arc supapa                | Spring                     | ps5500rs-1-27 |
| 28 | taler supapa              | Spring socket              | ps5500rs-1-28 |
| 29 | culbutori                 | Valve rocker               | ps5500rs-1-29 |
| 30 | piulita                   | Nut                        | ps5500rs-1-30 |
| 31 | piulita                   | Nut                        | ps5500rs-1-31 |
| 32 | garnitura capac culbutori | Gasket of Cylinder cover   | ps5500rs-1-32 |
| 33 | capac culbutori           | Cylinder Head cover        | ps5500rs-1-33 |
| 34 | deflector                 | Wind screen                | ps5500rs-1-34 |
| 35 | deflector                 | Wind screen 1              | ps5500rs-1-35 |
| 36 | supapa evacuare           | Exhaust Valve              | ps5500rs-1-36 |
| 37 | supapa admisie            | Intake Valve               | ps5500rs-1-37 |
| 38 | set segmenti              | Piston ring                | ps5500rs-1-38 |
| 39 | siguranta bolt piston     | Jump ring                  | ps5500rs-1-39 |
| 40 | bolt piston               | Pin                        | ps5500rs-1-40 |
| 41 | piston                    | Piston                     | ps5500rs-1-41 |
| 42 | ansamblu biela            | Connect rod assy.          | ps5500rs-1-42 |
| 43 | surub                     | Hexagon flange bolts       | ps5500rs-1-43 |
| 44 | modul aprindere           | Ignition Assy              | ps5500rs-1-44 |
| 45 | bujie                     | Spark Plug                 | br4t          |
| 46 | placa control             | Governor assy              | ps5500rs-1-46 |
| 47 | tija choke                | Choke rod                  | ps5500rs-1-47 |
| 48 | tija                      | Handspike of Valve         | ps5500rs-1-48 |
| 49 | arc                       | Draw spring                | ps5500rs-1-49 |
| 50 | prezon                    | Double head bolt           | ps5500rs-1-50 |
| 51 | garnitura izolator        | Gasket I of Air Inlet Pipe | ps5500rs-1-51 |
| 52 | furtun epurator           | Freather pipe              | ps5500rs-1-52 |
| 53 | izolator                  | Air Inlet Pipe             | ps5500rs-1-53 |
| 54 | garnitura carburator      | Gasket of Air Filter       | ps5500rs-1-54 |
| 55 | carburator                | Carburetor Assy            | ps5500rs-1-55 |
| 56 | garnitura filtru aer      | Gasket of Air Filter       | ps5500rs-1-56 |
| 57 | suport filtru aer         | bracket of air filter      | ps5500rs-1-57 |

## Producător motoutilaje

## Documentatie tehnică

|    |                      |                              |               |
|----|----------------------|------------------------------|---------------|
| 58 | filtru aer           | Foam Filter Element          | ps5500rs-1-58 |
| 59 | element filtrant     | Foam Filter Element          | ps5500rs-1-59 |
| 60 | capac filtru aer     | Upper cover                  | ps5500rs-1-60 |
| 61 | buson rezervor       | Fuel cover                   | ps5500rs-1-61 |
| 62 | burete               | Foam                         | ps5500rs-1-62 |
| 63 | garnitura buson      | Seal Gasket of Fuel Tank Cap | ps5500rs-1-63 |
| 64 | rezervor combustibil | Fuel tank                    | ps5500rs-1-64 |
| 65 | filtru combustibil   | Fuel filter net              | ps5500rs-1-65 |
| 66 | colier               | Twisting clip A              | ps5500rs-1-66 |
| 67 | furtun               | Fuel Inlet Pipe              | ps5500rs-1-67 |
| 68 | colier               | Twisting clip B              | ps5500rs-1-68 |
| 69 | bloc motor           | Crankcase                    | ps5500rs-1-69 |
| 70 | arbore cotit         | Crankshaft Assy              | ps5500rs-1-70 |
| 71 | ax came              | Camshaft                     | ps5500rs-1-71 |
| 72 | joja                 | Oil ruler assy               | ps5500rs-1-72 |
| 73 | ansamblu regulator   | Speed Regulator Gear Assy.   | ps5500rs-1-73 |
| 74 | saiba                | Cushion                      | ps5500rs-1-74 |
| 75 | saiba                | Curvy washer                 | ps5500rs-1-75 |
| 76 | bolt                 | Pin                          | ps5500rs-1-76 |
| 77 | capac carter         | Box cover                    | ps5500rs-1-77 |
| 78 | simering             | Oil seal                     | ps5500rs-1-78 |
| 79 | prezon m6x70         | Bolt III M6x70               | ps5500rs-1-79 |
| 80 | prezon m6x59         | Bolt III M6x59               | ps5500rs-1-80 |
| 81 | placa                | Fixed board                  | ps5500rs-1-81 |
| 82 | surub                | Hexagon flange bolts         | ps5500rs-1-82 |
| 83 | surub                | Hexagon flange bolts         | ps5500rs-1-83 |
| 84 | tija regulator       | Speed Regulator Rod          | ps5500rs-1-84 |
| 85 | arc                  | Draw spring                  | ps5500rs-1-85 |
| 86 | siguranta            | Split pin                    | ps5500rs-1-86 |
| 87 | surub                | Screw                        | ps5500rs-1-87 |
| 88 | oring                | Oil seal                     | ps5500rs-1-88 |
| 89 | saiba                | washer                       | ps5500rs-1-89 |
| 90 | brat regulator       | Speed Regulator Rocker       | ps5500rs-1-90 |
| 92 | surub                | Screw                        | ps5500rs-1-92 |