


Documentatie tehnica tornado 399



Nr. crt	Denumire produs	Product name	Cod comanda
1	inel siguranta	lock ring	pst399-01
2	capac inferior	pump base	pst399-02
3	burduf	rubber	pst399-03
4	condensator	capacitor	pst399-04
5	carcasa motor	motor frame	pst399-05
6	carcasa inferioara	bearing base	pst399-06
7	izolatie	insulation paper	pst399-07
8	saiba	wave washer	pst399-08
9	rulment	bearing	pst399-09
10	rotor	rotor	pst399-10
11	inel siguranta	lock ring	pst399-11
12	rulment	bearing	pst399-12
13	stator	stator with coil	pst399-13
14	protectie	protector	pst399-14
15	saiba etansare mecanica	mechanical seal washer	pst399-15
16	etansare mecanica	mechanical seal	pst399-16
17	izolatie	insulation paper	pst399-17
18	oring	o-ring	pst399-18
19	oring	o-ring	pst399-19
20	surub	bolt	pst399-20
21	surub	bolt	pst399-21
22	capac motor	oil chamber	pst399-22
23	cablu	cable	pst399-23
24	saiba	whaser	pst399-24
25	piulita	nut	pst399-25
26	oring	o-ring	pst399-26
27	surub	bolt	pst399-27
28	etansare mecanica	mechanical seal washer	pst399-28
29	inel siguranta	lock ring	pst399-29
30	sita	suction net	pst399-30
31	flansa	cover	pst399-31
32	snek	srew	pst399-32
33	bucsa snek	screw cover	pst399-33
34	manson	rubber seal	pst399-34
35	cap refulare	outlet	pst399-35
36	carlig	rings	pst399-36
37	prezon	long bolt	pst399-37
38	piulita	nut	pst399-38